



OBS.: Don't remove the wire washer.

1° Adjust the height and fix it with the cable holder as shown in the Fig. 01.

2° Install the driver with the cables as shown in the list below:

- Cables #1 Connect with red Driver1 Cable**
- Cables #2 Connect with black Driver1 Cable**
- Cables #3 Connect with red Driver2 Cable**
- Cables #4 Connect with black Driver2 Cable**

3° Fix the support on the ceiling.

4° Install the driver on electrical network.

5° Push the fixture as shown on the image above and fix the bushing on the bolt.

ML-2150 3000K 6600lm 33 7/8" x 1" x 1 1/8" (6 Stack) 120V **Power:** 48W **Weight:** 7.51 lbs

Product indicated for indoor areas.

Attention

Follow the instructions to ensure proper and safe operation. We recommend that the installation be done by a qualified professional. Recessed ceiling installation requires rigid support point attachment and special installations require special attachment.

Important

Lamps, transformers, and reactors are not included with the product except as noted. Failure to follow the instructions in the manual could result in accidents and loss of warranty. Do not adjust springs and brackets unless otherwise indicated.
 Warranty: 1 year for product and 5 years for Led and Driver.

Cleaning and Maintenance

Before any action turn off the electric current. Clean only with water dampened flannel, never use chemicals or abrasives. The materials that make up the product are non-toxic.