



Product indicated for indoor areas.

1° Make the niche in the ceiling, according to the measurements below

2° Position the frame in the niche; it will stay through the springs. Use a ruler to level the frame with the recessed ceiling.

3° Fill the gaps with plaster for fixing and finish the final with putty

4° Do the electrical installation in the socket

5° Insert the light bulb into the cup

6° Put the spring to fix the lamp

7° Put the cup again until it is fitted

8° Direct the focus where you want.

| | | | | | | |
|---------|--------------------|-------|-----------|----------------|------------------|------------------------|
| ML-2236 | Ø 2 7/8" x 3 3/8" | GU10 | 120V-277V | Power Max: 7W | Weight: 0.25 lbs | Cutting area: 3 1/8" |
| ML-2237 | Ø 3 3/4" x 5 1/8" | PAR20 | 120V-277V | Power Max: 8W | Weight: 0.31 lbs | Cutting area: 4 15/16" |
| ML-2238 | Ø 5 5/16" x 5 1/8" | PAR30 | 120V-277V | Power Max: 15W | Weight: 0.38 lbs | Cutting area: 5 9/16" |
| ML-2239 | Ø 5 5/16" x 4 3/4" | AR111 | 120V-277V | Power Max: 18W | Weight: 0.31 lbs | Cutting area: 5 9/16" |

Attention

Follow the instructions to ensure proper and safe operation. We recommend that the installation be done by a qualified professional. Recessed ceiling installation requires rigid support point attachment and special installations require special attachment.

Important

Lamps, transformers, and reactors are not included with the product except as noted. Failure to follow the instructions in the manual could result in accidents and loss of warranty. Do not adjust springs and brackets unless otherwise indicated.

Warranty: 1 year for product and 5 years for Led and Driver.

Cleaning and Maintenance

Before any action turn off the electric current. Clean only with water dampened flannel, never use chemicals or abrasives. The materials that make up the product are non-toxic.